

ICRI PHONE “PATCH”

The ICRI is configured with a small modular jack (RJ22) installed on its side. This jack will allow a user to quickly connect any radio to a standard telephone or a cell phone.

Setting up the land-line phone “patch”

Disconnect the coiled cable from the telephone’s handset; do not disconnect the cable from the base of the telephone.

Plug the cable directly into the jack on the side of the ICRI; the jack is labeled “TELEPHONE”



Remove the telephone’s handset from its cradle, and dial the telephone number of another telephone.

When the called party answers, use a remote radio to converse with called party.

Using a cellular telephone.

Plug the RJ22 connector on the cellular telephone interface cable (C-AT P/N 179.0717 or 179.0693) into the jack on the side of the ICRI; the jack is labeled “TELEPHONE”



Plug the small, single shaft 3.5mm connector to the cellular telephone’s headset jack.

Set the telephone into auto- answer mode

When the cell phone has been connected to an incoming call, use a remote radio to converse with the calling party.

For Additional Information...

G. Seth Leyman

President/Founder

Communications-Applied Technology

11250-14 Roger Bacon Drive, Reston, VA, 20190 USA

Voice: +1-703-481-0068; Fax: 703-471-4428

E-mail: leymans@c-at.com

Website: www.c-at.com

CAGE Code: 0EEY2, TIN: 54-1215868

DOL Veteran-owned, Small Business SIC 3669



MADE IN THE U.S.A